

OT BNC Installation Check List

- Strip cable & flare braid to specifications on bag.
- Ensure that center conductor is straight & free of burrs.
- Slide ferrule on (tapered or stepped end toward cable).
- Slide connector on cable until it bottoms out (if resistance occurs, back out cable to verify center conductor is still straight).
- Slide ferrule over braiding with a slight twist; capturing all of the braid.
- Hold assembly by ferrule and cable while terminating the center conductor with the plastic termination tool on a flat surface.
- Conduct light pull test to verify center conductor termination.
- Ensure that the rear ferrule is completely covering the braiding & crimp the rear ferrule.
- Check for coverage of braid after ferrule termination.

OT BNC Right Angle Boot Application

- When attaching right angle boot, make sure ferrule is completely inserted and allows view of the embossment.
- Right angle boot edge should be flush to the coupling nut upon completion.
- Right angle boot installation is easier when hex point is facing up.